


AD301 Installation Instructions



RJ11

- 1 No Connection
- 2 IR Positive
- 3 IR Negative
- 4 No Connection



RJ45

- 1 Audio Common
- 2 Volume Down
- 3 Audio Active
- 4 On/Off
- 5 Channel Down
- 6 Channel Up
- 7 +12 / 24 Volts DC
- 8 Volume Up

